

ONE TIME Pressure sensor setup (Only do this once)

1. Make sure that all sensors are turned off
2. Make sure that the USB is NOT plugged in
3. Make sure “Arduino IDE” is completely closed and close other programs that may be using USB
4. Open <https://github.com/Riaanshah09/pressure-sensor>
5. Press “setup.bat” (fourth row)
6. Click “download raw file”
7. Click “keep”
8. Click the folder icon (next to the trash bin)
9. Drag “setup” into desktop on the left hand side
10. Close the window
11. Click “open file” in your downloads
12. Go to your desktop and double click “setup”
13. Click “run”
 - a. This will install the python, which contains the code needed to run the program.
14. Plug the USB in
15. Turn on the sensors (switch on the side of them)
16. Press any key on your keyboard
 - a. This will install the software
17. Double click “start_sensors” on your desktop
18. Press any key to start recording the data
19. Put the sensors into whatever you want to put them in
20. When you are done testing, press “Ctrl, C”
 - a. This will stop recording the data
21. Press “Enter” on your keyboard
22. It will say “Terminate batch job”
 - a. Type “Y”
 - b. Then press enter
23. It will create an excel spreadsheet on your desktop.
 - a. There is a Data section and chart section on the excel spreadsheet
24. Done!

**AS LONG AS YOU DO NOT DELETE “SETUP_BAT,” “PRESSURE,” OR “START_SENSORS,”
YOU ONLY HAVE TO DO THIS ONCE!!!! UNDER THIS, THERE ARE SOME PROBLEMS YOU
MAY FACE, CALL: 617-893-8505 IF YOU HAVE ANY QUESTIONS**

PROBLEMS + SOLUTIONS

PROBLEMS YOU MAY FACE:

1. "Arduino not found" error

- Make sure the USB is plugged in firmly
- Try unplugging and replugging the USB

2. Sensors not responding / all showing 0

- Make sure all 3 sensor modules are turned on
- Try turning them off and back on
- Unplug and replug the USB

3. Excel file not appearing on Desktop

- Make sure you pressed Ctrl+C to stop, not closed the window
- Check your Downloads folder

4. Screen on module is blank/grey

- Make sure all 3 sensor modules are turned on
- Try turning them off and back on
- Unplug and replug the USB

5. Python doesn't show up on desktop

- Double click "setup_bat," again and let that run
- If that doesn't work: Reinstall Python from python.org
- Make sure to check "Add Python to PATH" during install

6. Setup.bat says "pressure.py not found"

- Delete start_sensors.bat from Desktop and run setup.bat again

7. Sensors showing inconsistent readings

- Turn them on and off again
- Make sure sensor pads are lying flat on the surface
- Check that all wire connections are secure